



Make template of 1 1/4" surfaced Pine.  
 Cleat of 1" x 8" surfaced Pine, clinch nailed.

Note: On outside of curves put handle of track wrench through hole, supporting on two ties at this point and block up on low rail until top of gauge is level.

N.P.R.y.  
Standard Plan  
of Track Tools.  
Ballast Template.

Scale: 3/4"=1'-0"

Oct. 24, 1914.

Approved: *[Signature]*  
 First Vice President.

*[Signature]* Gen. Manager.

*[Signature]* Gen. Manager.  
 A. M. Burt Chief Engr. M. of W.